

DENSO Health Scanner ICP-SC1-QB



ICP Medical®
by Cordica Medical

Basic Care & Maintenance

Dust and other foreign matter on the reading window can impede code input; regularly check for debris and remove it as the usage environment warrants.

To clean the window, first blow the dust away with an **airbrush or soft brush**. Then, wipe the reading window with a **cotton swab or similar soft cloth**.

If sand or hard particles have accumulated, **never rub the reading window**; doing so will scratch or damage it.

Advanced Care & Maintenance: Using Disinfectant or Soap



01/

Wet a soft cloth with our tested disinfectants or soaps.

02/

Gently wipe scanner body and reading window.

03/

Wipe remaining disinfectant or soap off scanner body and reading window.

CAUTION:

When using liquid or spray type disinfectants or soaps, **DO NOT** dip or directly spray on scanner.

DO NOT soak scanner in disinfectant, soap or water.

In case of product discoloration, stop using disinfectant immediately.

Tested Disinfectants and Soaps

We have confirmed no appearance, function or performance damage on the scanner based on a **once a day wipe test with the following products**:

- 91% Isopropyl Alcohol Solution
- 0.5% Hydrogen Peroxide Solution
- 3% Hydrogen Peroxide Solution
- Sani-Cloth® Bleach Wipes (PDI)
- Sani-Cloth® Plus Germicidal Wipes (PDI)
- Sani-Cloth® HB Germicidal Wipes (PDI)
- Sani-Cloth® PDI AF3 Wipes (PDI)



- Super Sani-Cloth® Wipes (PDI)
- Disinfecting Wipes: Bleach-free (Clorox)
- Formula 409 Multi-Surface (Clorox)
- Dispatch Wipes (Clorox)
- MetriCide 28 Day Solution: 2.5% Glutaraldehyde (Metrex)
- CaviWipesXL Disinfecting Towelettes (Metrex)
- Cidex OPA Solution (Advanced Sterilization Products)
- Oxivir Tb Wipes (Diversey)
- Virex II 256 Disinfectant Cleaner (Diversey)
- Hepacide Quat II (Spartan)
- Windex Original Spray (SC Johnson)
- Windex Multi-Surface Anti-Bacterial Spray (SC Johnson)